

QUICK GUIDE TO FIRST POWER UP

1 Mount the control panel to the wall

2 Connect the peripherals to the BUS.

3 Connect the BUS wires to the control panel.

4 Complete the wiring and balancing of the system detectors

5 Connect the detectors to the terminals

6 Connect the outputs to the control panel and peripheral terminals

7 Connect the control panel to the Internet

8 Insert the Smart-Logos30M to the motherboard (PCB)

9 Insert the maintenance jumper in the "SERV" position

10 Connect the primary power source (230V) (230V~ ±10%, 50/60Hz)

11 Connect the buffer battery and the thermal probe

12 Activate the control panel

13 Select the language


14 Set the addresses of the peripherals

15 Auto-enrolling peripherals



16 Acquire automatically the zone balancing via the installer menu

17 Specify the expansion terminals simulated by the Air2-BS200 as "Wireless" terminals

18 Insert the maintenance jumper in the "RUN" position



Terminal	icon/identifier	Function
1-2-3	NO NC COM	Voltage-free contacts of the relay output
4	+OC	13.8V 350mA ancillary power supply
5-6	OC1 OC2	Open-collector outputs
7-8-9-10	+ D S -	I-BUS connection
11-23	AUX1 AUX2	13.8V output terminals
25	AUX3	13.8V ancillary power supply
12-14-16-18-20-22-24-26-28-30-32-34-36	+/	Power supply negative (earth or GND)
13-15-17-19-21-27-29-31-33-35	T1-T2-T3-T4-T5-T6-T7-T8-T9-T10	Control panel input/output terminals
37-38		Internal telephone-line connection
39-40	PSTN	Land-line connection (PSTN)
/		Earth connection





Expansions and transceivers address	Red	Blue	Green	Yellow	nBy/S Air2-BS200	nBy/K Air2-BS200	nBy/X
1	0	0	0	1	0000	0	0
2	0	0	1	0	0000	0	0
3	0	0	1	1	0000	0	0
4	0	1	0	0	0000	0	0
5	0	1	0	1	0000	0	0
6	0	1	1	0	0000	0	0
7	0	1	1	1	0000	0	0
8	1	0	0	0	0000	0	0
9	1	0	0	1	0000	0	0
10	1	0	1	0	0000	0	0
11	1	0	1	1	0000	0	0
12	1	1	0	0	0000	0	0
13	1	1	0	1	0000	0	0
14	1	1	1	0	0000	0	0
15	1	1	1	1	0000	0	0
16	0	0	0	L	0000	0	0
17	0	0	L	0	0000	0	0
18	0	0	L	L	0000	0	0
19	0	L	0	0	0000	0	0
20	0	L	0	L	0000	0	0
21	0	L	L	0	0000	0	0
22	0	L	L	L	0000	0	0
23	L	0	0	0	0000	0	0
24	L	0	0	L	0000	0	0
25	L	0	L	0	0000	0	0
26	L	0	L	L	0000	0	0
27	L	L	0	0	0000	0	0
28	L	L	0	L	0000	0	0
29	L	L	L	0	0000	0	0
30	L	L	L	L	0000	0	0

12 Peripheral device addressing



During the addressing phase, do not exceed the maximum number of addresses available for the control panel model you are installing. For the readers addressing, use keypad "1".

LED Off	0	○
LED On	1	●
Flashing LED	L	○



CE
EN 50131-1
EN 50131-3
EN 50131-6
EN 50131-10
EN 50136-1
EN 50136-2
EN 50136-4
EN 50130-5
CEB TO31

PRIME

Installation and programming guide

inim®

Evolving Security

12 Activation of the control panel



Warranty

Inim Electronics S.r.l. warrants that this product shall be free of defects in material and workmanship for a period of 24 months from the date of production.

In consideration of the fact that Inim Electronics does not install directly the products here indicated, and due to the possibility they may be used with other products not manufactured by Inim Electronics, Inim Electronics cannot guarantee the performance of the security installation. Seller obligation and liability under this warranty are expressly limited to repairing or replacing, at seller's option, any product not meeting its stated specifications. In no case can Inim Electronics be held responsible or liable by the buyer or any other person for any loss or damage, direct or indirect, consequential or incidental, including, without limitation, any damages for lost profits, stolen goods or claims by any other party caused by defective products or otherwise arising from the incorrect or otherwise improper installation or use of these products.

This warranty applies only to defects in parts and workmanship relating to normal use. It does not cover misuse or neglect, damage caused by fire, flood, wind, lightning, vandalism or wear and tear.

Inim Electronics shall, at its option, repair or replace any defective products. Improper use, that is, use for purposes other than those mentioned herein will void this warranty. For further details regarding this warranty contact the authorized dealer.

Limited Warranty

Inim Electronics S.r.l. shall not be liable for any damage caused by improper use of this product.

The installation and use of the products indicated herein must be carried out by authorized persons only. Moreover, the installation procedure must be carried out in full respect of the instructions provided in this manual.

Leading-edge systems (DM 37/08)


The devices described in this manual, depending on the settings selected during the installation phase and the implementation of the concepts illustrated in this guide, allow you to create an Intrusion Detection and Hold-up Alarm System (I & HAS) compliant with EN 50131-1:2006 + A1:2009 + A2:2017 + A3:2020 and EN 50131-5-3:2017, safety grade 2 (at highest) and an alarm transmission system (ATS) compliant with EN 50136-1:2012 + A1:2018 in category ATS6 (at highest SP6 or DP4).

The devices described are compliant with European standards EN 50131-3:2009 (in reference to control and indicating equipment - CIE), EN 50131-6:2017 (in reference to power supplies - PS), EN 50131-10:2014 and EN 50136-2:2013 (in reference to transceivers on supervised sites - SPT).

As a support to the design, planning, operation, installation, commissioning and maintenance of intrusion alarm systems installed in buildings, the following regulatory documents should be consulted: CEI 79-3 and CEI CLC/TS 50131-7.

Depending on the State where the components described are installed, certified compliance with local laws and regulations may be required.

PROGRAMMING VIA KEYPAD EXAMPLE



This example describes the installation of a Prime system in a residential building. Ideally this procedure directly follows the instructions for the first startup of the system

Start programming

Type-in Code (Installer), PROGRAMMING

Programming partitions

Change the descriptions of the partitions:

- Partition 1 - "Ground floor"
- Partition 2 - "First floor"

PROGRAMMING Partitions, "Partition 00x", Description

Programming zones

Program the zones (all connected to the control panel):

PROGRAMMING Terminals, select the terminal concerned

or

PROGRAMMING Zones, select the zone associated with the terminal concerned

Description	Partition	Zone type	Option	Balancing	Detector type
A	Roller blind detector	Ground floor	Instant	None	Normally closed
B	Motion detector	Ground floor	Delayed	Interior	Normally closed
C	Magnetic sensor	Ground floor	Delayed	None	Normally closed
D	Magnetic sensor	Ground floor	Instant	None	Normally closed
E	Motion detector	Ground floor	Instant	None	Normally closed
F	Motion detector	First floor	Instant	None	Normally closed
G	Motion detector	First floor	Instant	None	Normally closed
H	Motion detector	First floor	Instant	None	Normally closed

Programming scenarios

Add a third partial arming scenario (Stay mode) to the default scenarios (Scenario 1 "Away mode" and Scenario 2 "Disarm") of both partitions.

PROGRAMMING Arming scenarios, "SCENARIO 003", Partitions, "Partition", Stay

Programming readers

Associate the "Ground floor" and "First floor" partitions with the readers, and scenario 3 Stay mode (arm partially) to the default scenarios:

PROGRAMMING Readers, ChoosePeripheral, "READER 00x", Partitions
In this section you can enable the "Ground floor" and "First floor" partitions.

PROGRAMMING Readers, ChoosePeripheral, "READER 00x", Shortcut
In this section you can select the shortcut associated with the red and blue LEDs by first selecting the "Arm/disarm" type then the scenario to associate with the LED.

	Description	Partitions	Red LED shortcut	Blue LED shortcut
I	Reader entrance door	Ground floor First floor	Default	Default
J	Keypad (built-in reader)	Ground floor First floor	Default	Execute "Scenario 3" arming mode
K	Reader bedroom	Ground floor First floor	Execute "Scenario 3" arming mode	Default

Programming keypad

Associate the keypad with the "Ground floor" and "First floor" partitions.

PROGRAMMING Keypads, ChoosePeripheral, KEYP. 001", Partitions
In this section you can enable the "Ground floor" and "First floor" partitions.

Programming expansions

To program the devices connected to the expansion terminals:

PROGRAMMING Terminals, select the terminal concerned
Press the **2abc** button to configure the terminal as an output.
Press **OK** to access the programming menu.

Terminal	Description	Type	Output options	Monostable time
L	1	Cancel	Output	Monostable 30 seconds
L	2	Garden lights	Output	Monostable Switch 60 minutes

Programming keys

Associate the keys ([M] and [N]) with the "Ground floor" and "First floor" partitions:

PROGRAMMING Keys, Change key, "Key 00x", Partitions
In this section you can enable the "Ground floor" and "First floor" partitions.

Enroll the keys, using one of the proximity readers and/or a keypad.

PROGRAMMING Keys, Enroll, "Reader 00x", "Key 00x"

Hold the key in the vicinity of the reader and then move it away. The keypad you are working on will emit a beep to confirm that the key has been enrolled.

Programming wireless keyfobs

Associate the shortcuts for the arm/disarm commands and control of expansion outputs to the keyfob command buttons [N]:

PROGRAMMING Keys, Change key, "Key 00x", Partitions

This section will allow you to associate the shortcuts that are not default shortcuts, specifically "Activate output" shortcuts. to buttons **F3** and **F4** then select the respective outputs on the expansion.

Button	Shortcut	Parameter	Default
N	F1	Arm/Disarm	Scenario 1 "Away"
	F2	Arm/Disarm	Scenario 2 "Disarm"
	F3	Activate output	Cancel
	F4	Activate output	Garden lights

Enroll the wireless keyfob via the simulated reader of the transceiver ([O], identified on the keypad by the letter "W").

PROGRAMMING Keys, Enroll, "READER 00x W", "Key 00x"

At this point you have 3 minutes to enroll the wireless keyfob by pressing simultaneously buttons **F3** and **F4**.

The positive outcome of the operation will be signalled by 3 blinks on the green LED of the wireless keyfob and a long audible signal on the buzzer.

Closing the programming session

Close the programming session after saving the modified data.

Press the **Esc** several times until the following message appears on the display:

EXIT? OK = YES

On pressing **OK** you will automatically exit the programming session, save the programmed data and reboot of the control panel.

FIRST OPERATIONAL TEST

A procedure is provided for an operational test on the Prime system after installation. The test consists in the violation of a "Delayed" type zone.

This procedure must be carried out only after the complete installation of the Prime control panel and of all the components that make up the entire installation. To do this it is advisable to follow the instructions provided in the quick guide to first power up.



1. Make sure all partitions are in stand-by status. This status is signalled on the blue LED on the keypad when is ON solid.
2. Enter the control panel programming phase and program the partition you intend to violate.

Type in Code (Installer), PROGRAMMING Terminals, select the terminal concerned or

Type-in Code (Installer), PROGRAMMING Zones, select the zone associated with the terminal concerned Once the section has been accessed, set the "Type" as "Delayed".

3. Set up the telephone dialer to provide voice signalling of violation.

Type in Code (Installer), PROGRAMMING Telephone, Number selected, "NUMERO 001"

Once in this section it is necessary to enter the number to call and set the "Type" as "Voice".

4. Exit the programming phase and carry out an Away Arming operation.

If the default programming has not been changed, it can be carried out as follows:

Activate the "Arm/Disarm" shortcut (shortcut no. 1) associated with the **F1** button shown on the display.

5. Wait until the "Exit Time" expires (30 seconds by default).

The keypads will emit a series of pulses (3 pulses + 5-second pause, 4 short pulses + 5-second pause during the last 20 seconds of the exit time).

6. Violate the programmed zone.

Test Entry time

7. Being a "Delayed" type zone, the "Entry Time" will begin (30 seconds by default).

The keypads will emit a series of pulses (8 pulses + 5 second pause).

Test alarm signalling

8. If the arming scenario is still active when the entry time expires, alarm signalling will trigger:

- The visual and audible alarm signals will activate
- The red LED on the keypad will blink rapidly

Dialer Test

9. The control panel will carry out signalling by means of a voice call to the programmed number.

10. Perform a disarm partitions operation. This operation also stops any alarms.

If the default programming has not been changed, it can be carried out as described below, following entry of the user code:

Activate the shortcut associated with **F2** button shown on the display. The shortcut will carry out a "Disarm" operation.

11. Delete alarm memories.

If the default programming has not been changed, it can be carried out as described below, following entry of the user code:

Activate the "Delete memory" shortcut (shortcut no. 4) associated with the **F4** button shown on the display.

12. Performing all the phases described above on a regular basis without problems is sufficient to confirm proper functioning and correct basic programming of the control panel.

DEFAULT PROGRAMMING

Keypads

- keypad "1" enabled
- all keypads belong to partition 1
- 12 programmed shortcuts: Execute Arming Scenario 1 - Execute Arming Scenario 2 - Delete telephone calls - Delete memory - Zone activation menu (bypasses) - View alarm log - View faults - Time/date setting - Voice function menu - Intercom call - Thermostat menu - Keypad settings menu
- all thermostats enabled on all keypads

nBy readers

- belong to partition 1
- shortcut programmed on the red LED: Execute Arming Scenario 1

Partitions

- entry time and exit time 30 seconds
- Autoreset memories on arming
- clear call queue on disarming

Terminals

- terminals on control panel: inputs
- terminals on expansion boards: inputs
- terminals on keypads: unused

Zones

- belong to partition 1
- have N.C. balancing (normally closed)
- zones T1 and T2 on the control panel are delayed; all other zones are instant
- unlimited alarm cycles (repetitive)

Outputs

- the output relay is monostable, normally closes, monostable time at 3 minutes
- the output relay is "Intrusion" type
- all other outputs are "generic"
- "AUX1" and "AUX2" outputs of the control panel are normally closed
- "AUX1" and "AUX2" outputs of all power-supply stations are normally closed

Virtual terminals

- all virtual terminals are input/output, "technological" and associated with partition 1

Expansions

- all expansions have anti-tamper disabled

Scenarios

- scenario 1: Away arm partition 1
- scenario 2: Disarm partition 1

Codes

- user code 1 belongs to all partitions
- all other codes do not belong to any partition
- only Code 1 is "Master" user
- enabled on all sections of the user menu
- 8 programmed shortcuts (F1-F4 keys): Clear call queue phone - Output 2 activation - Output 2 deactivation - View Zone status - View System status - Enable answerphone - Activate output scenario - Settings menu
- 6 programmed shortcuts (keys from 1 to 6): Listen-in - Execute arming scenario 1 - Execute arming scenario 2 - Stop alarms - Activate Output 2 - Deactivate Output 2
- voice guide enabled
- all terminals configured as "output" or "I/O" are associated with all codes

Keys

- belong to partition 1
- Maintenance option enabled

Telephone

- numbers 1 to 6 in the contacts list have the voice attribute (user)
- numbers 7 and 8 in the contacts list are for alarm receiving centres CONTACT-ID
- contact number 9 in the phone book has the voice attribute (for the installer)
- contact number 15 is for teleservice

Zone alarm/tamper

TECHNICAL FEATURES

Control panels - electrical and mechanical features

Control panel models		Prime060S	Prime060L	Prime120L	Prime240L	Prime500L
Voltage	power supply	230V ~ -15% +10% 50/60Hz				
	nominal output	13.8V ^{***}				
	output range	from 9 to 13.8V ^{***}				
Current absorption	maximum	0.5A		1.1A		
	of the control panel motherboard	180mA @ 13.8V				
Fault voltage on power outputs		9.8V				
Protection tripping voltage	from deep discharge	9.5V				
	from overload	15.4V				
Maximum power-supply voltage ripple		550mV		200mV		
PS type		A				
Maximum voltage on I-BUS		4A				
Type of alarm notification (EN 50131-1, par. 8.6)		D				
IP Protection grade		30				
Enclosure Dimensions (W x H x D)		27.5 x 37.4 x 8.6 cm		37.5 x 46.6 x 9.2 cm		
Weight (without battery)		3.2Kg		5Kg		
Security grade	EN50131-3	3				
	EN50131-6	3				

Control panels - main features

Control panel models		Prime060S	Prime060L	Prime120L	Prime240L	Prime500L
Partitions		10		20		30
Total zones		120		240		1000
Keypads		30				
Voice memo slots		10				
Expansions		100				
Readers		60				
Sounder/flashers		10				
Wireless transceiver		20		30		
Digital keys and wireless command devices		150				
Possible key combinations		4294967296				
Isolators		16				
GSM, GPRS, UMTS, HSPA and LTE communicator		1				
Temperature probes		15				
Home-automation modules		30				
Wi-Fi boards		1				
Codes		50		100		500
Scenarios		50				
Timers		40				
Recordable Events		4000				
Programmable events		60				

Number of terminals

Control panel models		Prime060S	Prime060L	Prime120L	Prime240L	Prime500L
Terminals on panel	total	10				
	configurable as inputs	10				
	configurable as rollerblind/shock	10				
	configurable as outputs	10				
Wireless terminals		60		120		195
terminals on keypads		20		30		60
terminals on expansion boards	total	500				
	available	60		120		240
Virtual terminals		15				
Total terminals		60		120		500
Outputs on control-panel motherboard	total	15				
	terminals (T1, ..., T10)	10				
	relay	1				
	open collector (OC1, OC2)	2				
Auxiliary outputs (AUX1, AUX2)		2				

Type SD and distribution of the currents

Control panel models		Prime060S	Prime060L	Prime120L	Prime240L	Prime500L
SD type (backup battery)	rated voltage	12V				
	maximum capacity	7Ah	9Ah	17Ah	18Ah	17Ah
	maximum recharge time	24h (80% charged)				
	maximum internal resistance (R _i max)	1.50Ohm				
	low battery voltage	11V				
	battery recovery voltage	12V				
Maximum deliverable current @ 12V for external loads	total	3.2A				
	autonomy 30h	50mA	120mA	380mA	420mA	380mA
	autonomy 12h	400mA	570mA	1230mA	1320mA	1230mA
	autonomy 4h	1570mA	2070mA	4070mA	4320mA	4070mA
Max. current available on each +AUX terminal		1500mA				
Maximum deliverable current to open-collector outputs		T1, .., T10	250mA			
		OC1, OC2	500mA			



EN IEC 62368-1

Isolation class	I	
Terminal type	AC input	ES3, PS3
	BAT-, BAT+	ES1, PS2
	+ D S -	ES1, PS2
	AUXn, +12V	ES1, PS2
	NO NC COM	ES1, PS2
	Tn, OCn	ES1, PS1
	OUTn (Flex5/R, Flex2R/2T)	ES3, PS3
	Cn, NOn, NCn (AUXREL32)	ES1, PS2
	, PSTN	ES2, PS1
	RS232	ES1, PS1
	Ethernet (PrimeLAN)	ES1, PS1
	USB	ES1, PS1
	ANT (Nexus, PrimeWiFi)	ES1, PS1

Directive 2014/53/EU

Hereby, INIM Electronics s.r.l., declares that the following devices are in compliance with the essential requirements and other relevant provisions of Directive 2014/53/UE:

Prime 500L, Prime 240L, Prime120L, Prime060L, Prime060S

All the devices mentioned here above can be used in all EU countries without restrictions.

Processing of personal data

Prime control panels, by attributing them to installers and users registered with the Inim Cloud service, can be managed through dedicated web pages and/or apps available to both the installer and the end user.

In order to allow management of the control panel via Inim Cloud an explicit request is required from the users to whom the control panel is to be associated.

As soon as a control panel is connected to a LAN or a GSM/LTE network, it will be available on the Inim Cloud, however, until the association is explicitly requested by a user the data exchanged are:

- purely technical (in order to allow an association to a user in the future) and do not include any personal data
- always encrypted
- free from any correlation with personal data that may already be present in the Inim Cloud

The control panel events log becomes available only after associating the control panel with the users and can be viewed chronologically from the moment of such an association.